



If you have any questions about your monitor please contact us  
toll free at **888-998-9848**




Virgin (VMI) is the Parent Company of Hitman Drums  
Virgin Musical Instrument Company  
P.O. BOX 2908  
LA MESA, CA 91943

[info@virginmusicalinstruments.com](mailto:info@virginmusicalinstruments.com)  
[www.virginmusicalinstruments.com](http://www.virginmusicalinstruments.com)

**HITMAN** | HD-M1  
INSTRUMENT MONITOR  
W/ BT-1 BLUETOOTH RECIEVER

**USER'S MANUAL**

# IMPORTANT SAFETY INSTRUCTIONS



This symbol is intended to alert the user to the presence of non-insulated “dangerous voltage” within the products enclosure.



This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the unit.



Apparatus shall not be exposed to dripping or splashing. Objects filled with liquids, such as vases, shall not be placed on the apparatus.


1. Read all safety and operating instructions before using this product.
2. All safety and operating instructions should be kept for future reference.
3. Read and understand all warnings listed on the operating instructions.
4. Follow all operating instructions to operate this product.
5. This product should not be used near water, i.e., bathtub, sink, swimming pool, wet basement, etc.
6. Only use dry cloth to clean this product.
7. Do not block any ventilation openings, it should not be placed flat against a wall or placed in a built-in enclosure that will impede the flow of cooling air.
8. Do not install this product near any heat sources such as radiators, heat registers, stoves or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus. Do not break the ground pin of the power supply cord.
11. Only use attachments specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer or sold with the apparatus. When a cart is used, exercise caution when moving.
13. Unplug this apparatus during lightning storms or when unused for a long period of time.
14. Care should be taken so that objects do not fall and liquids are not spilled into the unit through the ventilation ports or any other openings.
15. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way.
16. **WARNING:** To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.
17. When a mains plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.

## FCC Statements

1. Caution: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
2. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

# Connection Panel



- 1 **DRUM IN:** 1/4" stereo instrument input jack
- 2 **LINE IN:** 1/4" stereo auxiliary input jack
- 3 **HEADPHONE:** 1/4" stereo headphone output jack
- 4 **DRUM VOLUME:** Volume control for DRUM IN input
- 5 **LINE VOLUME:** Volume control for LINE IN input
- 6 **EQUALIZATION:** Controls for overall tone  
**BASS** - Controls frequencies centered at 50Hz  
**MIDDLE** - Controls frequencies centered at 800Hz  
**TREBLE** - Controls frequencies centered at 10kHz
- 7 **BLUETOOTH RECIEVER INPUT:** Input for included bluetooth reciever
- 8 **BLUETOOTH ON/OFF:** Turns bluetooth functionality on or off
- 9 **POWER ON/OFF:** Turns power to the unit on or off
- 10 **POWER "ON" INDICATOR**

## Connecting a Bluetooth device

The included BT-1 Bluetooth Reciever allows you to play along with your favorite songs from Bluetooth compatible devices

1. With the unit powered off, connect the BT-1 Bluetooth reciever via the BLUETOOTH input on the control panel.
2. Turn the unit on, and swith the BLUETOOTH ON/OFF switch to on.
3. Your Bluetooth device will find the BT-1 as an option, select the BT-1 to connect. When connected succesfully the indicator light on the reciever will stay on.
4. Use your Bluetooth device to access the media you would like to play through the monitor.

### • TROUBLESHOOTING

Please make sure the volume of the monitor and the Bluetooth device is turned up.  
 If you are unable to connect to your Bluetooth device, please make sure that any other previously connected device has been disconnected.  
 If you are still unable to connect, please turn the Bluetooth function on your device off, and then back on to attempt to connect.  
 To change Bluetooth devices during normal operation disconnect the first device and reconnect to the new device following the above instructions.